

## PROCEDURE TO CLEAN FOREVERBREATHE PAINT SURFACES OVER MAGNUM

To be read in conjunction with Cleaning Video



Foreverbreathe paint surfaces and Magnum Board are natural products. Only natural, plant chemistry (Non – Corrosive) cleaners shall be used. Paint shall be 14 days cured prior to cleaning.

## **Surface Preparation**

- 1/ Use clean, warm water with a light dilution of Natural Detergent in conjunction with a non-abrasive clean white cloth (Cotton).
- 2/ Soak the cloth in the water and detergent solution to completely dampen.
- 3/ Dab the soiled area with the intension to "wet" the surface before wiping.
- 4/ Once completely wet, lightly wipe the surface with the cloth using long gentle strokes.

The objective is to allow the soil to be lifted or loosened from the surface to help remove the soiling without harsh scratching. Magnum Board will allow the surface to take water which will help this process.

## **Stubborn Marks**

- 1/ Use clean, warm water with a light dilution of Natural Detergent in conjunction with a non-abrasive clean white cloth (Cotton).
- 2/ Soak the cloth in the water and detergent solution to completely dampen.
- 3/ Dab the soiled area with the intension to "wet" the surface before wiping.
- 4/ Once completely wet, lightly wipe the surface with a Scotch- Brite Magic Eraser using long gentle strokes.
- 5/ Wipe back with clean cloth to finish

The objective is to allow the soil to be lifted or loosened from the surface to help remove the soiling without harsh scratching. Magnum Board will allow the surface to take water which will help this process.